

## Solar Shield - Polycarbonate Roofing Screws



### Features

22mm EPDM sealing washer

50mm x 12g screws

Galvanised to last

Complies to AS 3566 standard class 4



### Fixing instructions

1. Pre-drill a 10mm clearance hole through to the peak of the corrugation.
2. Fasten the roofing screw through to the purlin.
3. Then ease off until the sheet returns to its normal shape.

### Number of packs (50 per pk) of screws required for the Solar Shield polycarbonate roofing

Length	1	2	3	4	5	6	7	8	9	10
1800mm	1	1	1	2	2	2	2	3	3	3
2400mm	1	1	2	2	2	3	3	3	4	4
3000mm	1	1	2	2	3	3	4	4	4	5
3600mm	1	2	2	2	3	3	4	4	5	5
4800mm	1	2	2	3	4	4	4	5	5	6
5400mm	1	2	3	3	4	4	5	5	6	6

Plastics sales & distribution.

Ph 03 338 7050 Email [sales@cebelio.co.nz](mailto:sales@cebelio.co.nz) Web [www.cebelio.co.nz](http://www.cebelio.co.nz)

